



# Pre-adjustment water volume for Vario-DP



## Adjustment table

Pre-adjustment	1	1•	1••	1•••	2	2•	2••	2•••	3	3•	3••	3•••	4	4•	4••	4•••	5	5•	5••	5•••	6	6•	6••	6•••	7	7•	7••	7•••	8
		Water volume in l/h:																											
Differential pressure: 15–70 kPa	20 20 25 25 35 40 45 55 65 80 90 100 115 135 145 160 170 185 200 215 230 245 260 275 290 300 315 330 340																												

### Example valve pre-adjustment



- 1 Indication pre-adjustment
- 2 Main adjustment value
- 3 Fine adjustment